

Powerpole® High Power PCB-Mounted Connector

Loose-Piece Assembly Instructions

1. Insert contact into housing using Anderson Power Products® Insertion/Extraction. Tool Part# 111038G2 as shown in Figure 1. (butt tool against alignment wedge on contact).
2. Push contact into housing until you hear a distinct click (Figure 2).
3. Tug on solder tail. Contact should not pull out of housing.
4. Inspect nose of housing to ensure contact hook is completely over the spring.

Connector is now ready for soldering to PCB (ref. APP drawing B02021S for PCB foot print).

NOTES:

Multipole Connections

When using multipole connections, housing dovetails should be mated fully prior to insertion of contacts.

Mounting Wings

When using mounting wings; the wing and Powerpole® dovetails should all be mated fully prior to insertion of contacts.

- Insert contacts as outlined in steps 1-4 above in all Powerpole® housings
- Insert all solder tails into PCB plated through holes
- Secure connector assembly to PCB after soldering operations are complete



Figure 1 - Inserting Contact Using Insertion Tool



Figure 2 - Full Insertion





Figure 3 - Multi-Row Block Construction Steps; Block Housings, Insert Lower Row Contacts, Insert Upper Row Contacts

WARNING

EXTREME CAUTION SHOULD BE USED WHEN WORKING ON LIVE CONNECTOR CONTACTS

TRADEMARKS

"Powerpole" and "Anderson Power Products" are registered U.S. and foreign trademarks of Anderson Power Products.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF ANDERSON POWER PRODUCTS. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF ANDERSON POWER PRODUCTS IS PROHIBITED



HEADQUARTERS: 13 Pratts Junction Road, P.O. Box 579, Sterling, MA 01564
T:978-422-3600 F:978-422-3700

EUROPE: Rathealy Road, Fermoy Co. Cork, Ireland T:353-(0)25-32277 F:353-(0)25-32296

ASIA/PACIFIC: IDEAL Anderson Asia Pacific Ltd., Unit 922-928 Topsail Plaza, 11 On Sum Street, Shatin N.T., Hong Kong T:852-2636-0836 F:852-2635-9036

CHINA: IDEAL Anderson Technologies (Shenzhen) Ltd., Block A8 Tantou W. Ind. Par, Songgang Baoan District, Shenzhen, P.R. China 51810 T: 86-755-2768-2118 F: 86-755-2768-2218

TAIWAN: IDEAL Anderson Asia Pacific Ltd., Taiwan Branch, 4F.-2, No.116, Dadun 20th St., Situn District, Taichung City 407, Taiwan (R.O.C.) T: 886-4-2310-6451 F:886-4-2310-6460

www.andersonpower.com

1S6479 REV01 ASM-HPPCB45